

















UNI.SOFY CRIB

Assembly Instruction - 1









A 	B 	C 	D 
4	4	4	8
E 	F 	G 	H 
4	4	8	8
J 	K 	L 	M 
1	4	8	4
N 	O 	P 	
4	2	1	

NO	W	x	L	x	H
01	1092	x	170	x	25
02	500	x	170	x	25
03	946	x	706	x	18
04	1180	x	555	x	8
05	946	x	706	x	18
06	1210	x	637	x	30
07	1200	x	637	x	30

UNI.SOFY CRIB

Assembly Instruction - 3



UNI.SOFY CRIB

Assembly Instruction - 4

