





# ORIGAMI - WALL UNIT

## Assembly Instruction - 1












NO	W	X	L	X	H
01	1380	x	268	x	25
02	495	x	250	x	18
03	495	x	230	x	18
04	235	x	230	x	25
05	479	x	230	x	25
06	495	x	230	x	25
07	495	x	268	x	25
08	504	x	1346	x	8
09	1380	x	268	x	25
10	485	x	230	x	18
11	489	x	521	x	18

Accessory	A	B	C	D	E	F	G	H	J	K	L
Quantity	14	8	22	18	4	4	4	4	4	2+2	4



# ORIGAMI - WALL UNIT

## Assembly Instruction - 2



# ORIGAMI - WALL UNIT

Assembly Instruction - 3

